

# INTELLISAT

# Tel: 1300 551616

LNBF

POLARISATION

OPTUS C1

## LNBF POLARISATION

Low Noise Block Converter & Feed

Polarisation Angle to Satellite

Note: Polarisation Angles refer to Vertical Axis

Manually adjust LNBF on roof of vehicle

Example: **Melbourne** = **-31 degrees**  
**Sydney** = **-38 degrees**  
**Perth** = **0 degrees**  
**Darwin** = **+18 degrees**

